

USB interface setting for Z-5111/Z-3100/Z-3101/Z-3110/Z-3151HS

Start



..



USB0

End



+-